

Raspberry Pi - Support #417

Changing the Stock Resolution on Raspbian

07/12/2014 12:15 PM - Daniel Curtis

Status:	Closed	Start date:	07/12/2014
Priority:	Normal	Due date:	
Assignee:	Daniel Curtis	% Done:	100%
Category:		Estimated time:	0.10 hour
Target version:		Spent time:	0.50 hour
Description			
<p>While setting up a Raspbian system, I found the need to change the resolution. Unfortunately, Raspbian sets the default resolution to 1900x1080 and makes the resolution unchangeable.</p> <p>To work around this problem, the config.txt in the /boot section needs to be modified.</p> <ul style="list-style-type: none">• Make the following changes to set the resolution to 1024x768: <pre>sudo vi /boot/config.txt</pre> <pre>hdmi_group=2 hdmi_mode=16</pre>			

History

#1 - 07/24/2014 09:28 AM - Daniel Curtis

- Status changed from New to Closed